OPERATION MANUAL 16" & 20" Stuffing Box Sheave Brackets Manufactured by Wireline Technologies, Inc.



Serial Number

Introduction

This manual explains the use and care of 16" and 20" stuffing box sheave brackets manufactured by Wireline Technologies, Inc. These sheaves feature a patented, spring-loaded, top entry shroud for easy loading and unloading. See figure 1. This system includes two line retainers that lower into the groove of the wheel and entrap the line prevent line jumping. See figure 2. They are available in two model types. The standard aluminum model is shown in figure 3. The stainless steel model is shown in figure 4. Both models are available in a 16" and a 20" size. The stainless steel brackets are stronger and, consequently, have higher safe working loads. Please read and become familiar with all of the information in this manual before using this equipment.





Top Entry Shroud Figure 1

Line Retainer Figure 2



Stainless Model (20" shown)

Figure 4

Aluminum Model (16" shown) Figure 3

<u>Warnings</u>

- Read entire manual before operating this equipment.
- If proper procedures are not followed, loads may disengage.
- A falling load can cause serious injury or death.
- Never use this product for hoisting personnel.
- Always anchor the sheave via bearings in the base, never by way of the side plates or any ancillary equipment.
- Never apply more force than the Safe Working Load (SWL) listed on the affixed tag.
- The listed Safe Working Load is for the sheave assembly; the safe line tension will be less.
- Attachment to other equipment with lower SWL will reduce the allowable load.
- Always make sure the assemblies are properly maintained and properly rigged.

Safe Working Load

The listed safe working loads (SWL) for WTI stuffing box sheave brackets is for 180-degree pulls. In this case the safe line pull will be 50% of the safe working load. If pulling at an angle away from the assembly the safe line pull will vary. See figure 5. Angles are measured from the stuffing box not necessarily from vertical. Consult table 1 below to determine the safe line pull. Never exceed the SWL, unless special precautions are taken in accordance with your company's policy. These precautions should include, but are not limited to, clearing the rig floor of all personnel. If the SWL is exceeded, the sheave should be re-certified before it can safely be placed back in service.

			1			
	Aluminum Stainless				s Steel	
Angle	16"	20"	Angle	16"	20"	
	3,000 lbs	3,000 lbs		5,000 lbs	5,000 lbs	
0	1,360 kg	1,360 kg	0	2,260 kg	2,260 kg	
	3,000 lbs	2,600 lbs		5,000 lbs	4,350 lbs	
Up to 10	1360 kg	1,180 kg	Up to 10	2,260 kg	1970 kg	
	2,850 lbs	2,350 lbs		4,750 lbs	3,900 lbs	
10 to 20	1290 kg	1,060 kg	10 to 20	2150 kg	1,770 kg	
	2,600 lbs	2,150 lbs		4,300 lbs	3,600 lbs	
20 to 30	1,180 kg	975 kg	20 to 30	1,950 kg	1,630 kg	
	2,300 lbs	1,950 lbs		3,800 lbs	3,300 lbs	
Over 30	1,040 kg	880 kg	Over 30	1,720 kg	1,500 kg	
		Safe	e Line Pull			
Angle of]	L I	Table 1			
Line Pull						
Figure 5						

Base Options

Four base options are available to fit different stuffing boxes. These options are shown in figures 6 below. The B1 Base fits the Bowen stuffing box. The W base fits the Western Pressure Control stuffing box. The H base fits the Halliburton/Otis stuffing box design. And, the E base fits the Elmar stuffing box. Each base comes with the appropriate bearings to fit the respective stuffing box. Other bases are available upon request.



Loading

The part numbers listed refer to figure 11 and table 2 on pages 9 and 10.

1. Remove ball-lock pin (7). See figure 6.

!<u>Caution!</u> Take care not to be struck by the shroud as the spring lifts it away from the wheel.

- 2. Load the line through the opening in the shroud system and into the groove of the wheel (35). See figure 8.
- 3. Push the shroud (1) back down and make sure the line is below the line retainers (4). See figure 9.
- 4. Reinstall the ball-lock pin and make sure it is secure.







Remove Ball-Lock Figure 7 Load Line Figure 8

Line Below Retainers Figure 9

Daily Inspection Checklist

Verify the following. If any discrepancies are noted, remove the sheave from service until repairs are completed. Numbers listed refer to figure 11 and table 2 (pgs. 9-10).

- □ All structural components (20, 24,25,35,36) are not bent, cracked, or otherwise damaged.
- □ Shroud (1) moves up and down freely.
- □ Ball-lock pin (6) removes and installs easily.
- □ Manufacturing label (32) is in place and readable.
- □ Inspection label (39) is in place on the rear plate and stamped with an inspection date no greater than one year old.
- □ Spiral pins (17) are in place and securely retain the slotted nuts (18) on the axle shaft (25).
- □ Wheel (35) rotates freely and smoothly, check for any grinding or sticking, indicating damaged bearings.
- \Box Retaining pin (5) is securely retaining the long slide (13).

Preventative Maintenance

WTI suggests the following service. Numbers listed refer to figure 11 and table 2 (pgs. 9-10).

- The wheel bearings (29) are sealed and only need annual re-packing. Use lithium based No.2 EPHT grease, such as Conoco's Tacna® RX. This service can be performed at the same time as the annual recertification. See page 7.
- □ Monthly, squirt some light machine oil on both slides (13,38) and the ball-lock pin (6).

Recertification and Repairs

WTI highly recommends yearly recertification of all stuffing box sheave brackets. Most companies mandate annual recertifications so this should not be overlooked. A tag on the rear of the assembly, shown in figure 10, provides a visible place to stamp certification dates. When a new sheave bracket is placed into service, stamp the current date into this tag. When the date becomes a year old, the assembly should be recertified. Each time it is re-certified a new date will be stamped in this tag. Upon completion of a repair or recertification, note the information in the log in the back of this manual. Re-certification involves the following:

- 1. Proof testing.
- 2. Disassembly.
- 3. Cleaning
- 4. NDT inspection of all of the load-bearing components.
- 5. Replacement or repair of any damaged or worn components.
- 6. Updating components for safety and easier use.
- 7. Packing the bearings with grease.
- 8. Re-assembly.
- 9. Pre-loading the bearings.
- 10. Documentation of all changes.
- 11. Final Inspection.
- 12. Issuance of a new certification.



Inspection Tag Figure 10

Recertification and/or repairs can be done one of three ways.

- Send the assembly to Wireline Technologies, Inc. Please call to make arrangements.
- Send the assembly to an authorized service center. Call to determine the nearest location.
- Determine if your company will allow recertification on site. If so, WTI can supply you with the training and documents needed.

Call Wireline Technologies Inc. (800) 743-2831. Use the drawings in figure 11 on page 9 to identify parts. The numbers in the circles correspond to the item numbers in table 2 on page 10.

<u>Notes</u>



ITEM PART NUMBER DESCRIPTION		QTYMATERIAL		ITEM	PART NUMBER	DESCRIPTION		MATERIAL	
1	SB-16-101-M	16" SHROUD	1	A-356	23	SB-138	NYLOC NUT 1/2"-13	5	18-8 S/S
OR	SB-20-101-M	20" SHROUD	1	A-356	24	SBA-130M-B1	BASE FOR B1 STYLE - ALUMINUM	1	A-356
2	SB-121	SOC HD CAP SC 3/8"-24 X 1"	2	18-8 S/S	OR	SBA-130M-W	BASE FOR W STYLE - ALUMINUM	1	A-356
3	SB-103	PAN HD SLOT M SC 1/4"-28 X 1"	4	18-8 S/S	OR	SBA-130M-H	BASE FOR H STYLE - ALUMINUM	1	A-356
4	SB-104	LINE RETAINER	2	6061-T6, ANOD.	OR	SBA-130M-E	BASE FOR E STYLE - ALUMINUM	1	A-356
5	SB-105	RETAINING PIN 3/8" X 1.25"	1	18-8 S/S	OR	SBS-130M-B1	BASE FOR B1 STYLE - STAINLESS	1	17-4PH S/S
6	SB-111	BALL LOCK PIN 3/8" X 1.25"	1	17-4 PH S/S	OR	SBS-130M-W	BASE FOR W STYLE - STAINLESS	1	17-4PH S/S
7	RS-1031	LANYARD 3/32" X 10.5"	1	18-8 S/S	OR	SBS-130M-H	BASE FOR H STYLE - STAINLESS	1	17-4PH S/S
8	RS-1032	LOOP FERULE 3/32"	2	COPPER	OR	SBS-130M-E	BASE FOR E STYLE - STAINLESS	1	17-4PH S/S
9	SB-123-B1	BEARING CONE FOR B1 STYLE BASE	2	ALLOY STEEL	25	SB/SL-116	AXLE SHAFT	1	303 S/S
OR	SB-123-W	BEARING CONE FOR W STYLE BASE	2	ALLOY STEEL	26	SB/SL-140	OUTER O-RING - 16"/20"	2	BUNA N
OR	SB-123-H	BEARING CONE FOR H STYLE BASE	2	ALLOY STEEL	27	SB/SL-141	INNER O-RING - 16"/20"	2	BUNA N
OR	SB-123-E	BEARING CONE FOR E STYLE BASE	2	ALLOY STEEL	28	SB/SL-109	O-RING SEAT	2	6061-T6, ANOD.
10	SB-122-B1	BEARING CUP FOR B1 STYLE BASE	2	ALLOY STEEL	29	SB/SL-142	BEARING CUP & CONE - 16"/20"	2	ALLOY STEEL
OR	SB-122-W	BEARING CUP FOR W STYLE BASE	2	ALLOY STEEL	30	RS-1010	WOODRUF KEY #807	1	316 S/S
OR	SB-122-H	BEARING CUP FOR H STYLE BASE	2	ALLOY STEEL	31	RS-1071	DRIVE SCREW 1/8" X 3/8"	8	18-8 S/S
OR	SB-122-E	BEARING CUP FOR E STYLE BASE	2	ALLOY STEEL	32	SBA-16-1077	MANUFACTURING LABEL - 16" ALUM.	1	LAM. PAPER
11	RS-1039	GREASE FITTING 1/8" NPT	1	STEEL, ZINC PL	OR	SBA-20-1077	MANUFACTURING LABEL - 20" ALUM.	1	LAM. PAPER
12	RS-1272	SPIRAL PIN 1/4" X 1 1/4"	2	420 S/S	OR	SBS-16-1077	MANUFACTURING LABEL - 16" S/S	1	LAM. PAPER
13	SB-120	LONG SLIDE	1	303 S./S	OR	SBS-20-1077	MANUFACTURING LABEL - 20" S/S	1	LAM. PAPER
14	SB-102	SPRING	1	302 S/S	33	SB/SL-114	HUB	1	6061-T6, ANOD.
15	SB-131	LONG OUTER TUBE	1	303 S/S	34	SB/SL-139	RETAINING CLIP 3/32" X 1/8" X 1 1/2"	1	ULTEM 1000
16	SB-135	FLAT HD SOC M SC 3/8"-16 X 1"	5	18-8 S/S	35	SB/SL-16-113	16" WHEEL (-XX FOR LINE SIZE)	1	NYLON W/ MoS2
17	SB/SL-106	SPIRAL PIN 3/16" X 1"	2	420 S/S	OR	SB/SL-20-113	20" WHEEL (-XX FOR LINE SIZE)	1	NYLON W/ MoS2
18	SB/SL-108	SLOTTED NUT 5/8"-18	2	18-8 S/S	36	SBA-16-134	LONG SIDE PLATE - 16" ALUMINUM	1	6061-T6, ANOD.
19	SB/SL-107	FLAT WASHER 5/8"	2	18-8 S/S	OR	SBA-20-134	LONG SIDE PLATE - 20" ALUMINUM	1	6061-T6, ANOD.
20	SBA-16-133	SHORT SIDE PLATE - 16" ALUMINUM	1	6061-T6, ANOD.	OR	SBS-16-134	LONG SIDE PLATE - 16" STAINLESS	1	304 S/S
OR	SBA-20-133	SHORT SIDE PLATE - 20" ALUMINUM	1	6061-T6, ANOD.	OR	SBS-20-134	LONG SIDE PLATE - 20" STAINLESS	1	304 S/S
OR	SBS-16-133	SHORT SIDE PLATE - 16" STAINLESS	1	304 S/S	37	SB-132	SHORT OUTER TUBE	1	303 S/S
OR	SBS-20-133	SHORT SIDE PLATE - 20" STAINLESS	1	304 S/S	38	SB-119	SHORT SLIDE	1	303 S/S
21	SB-136	HEX HD CAP SC 1/2"-13 X 3.25"	5	18-8 S/S	39	RS-1279	WTI INSPECTION LABEL - SQUARE	1	AL
22	SB-137	FLAT WASHER 1/2"	10	18-8 S/S					

Table 2. Bill of Materials

Recertification and Repair Log

Serial Number_____

Date	Recert	Repair	Performed by:	Notes

Date	Recert	Repair	Performed by:	Notes

Warranty

For a period of one year from the date of purchase, Wireline Technologies, Inc., will repair or replace, at its option, any 16" or 20" stuffing box sheave bracket of its manufacture that fails because of a defect in materials or manufacture, or which fails to conform to any implied warranty not excluded herein. This warranty does not cover damages caused by abuse, misuse, neglect, or overloading; and does not cover any incidental damages caused by a failure of this product.

<u>Notes</u>

<u>Notes</u>

Declaration of Conformity Ш

The following equipment:

P/N-

S/N

Date

Complies with the essential requirements of The European Union Machinery Directive 98/37/EC.



George Vent (V.P. Quality)



2140 North Redwood Road - #60 Salt Lake City, UT 84116 - USA www.wtisheave.com (800) 743-2831

Doc. # WTI-114 Rev. 1 (16-Jan-2008)